# WeighVault®



### **Standard Features**

- Specialized PC software makes data entry easy
- Boost product ID storage to nearly limitless potential, and manage as many scales as necessary
- Eliminates front-panel entry of ID parameters
- Quickly program, edit and manage scales and each unique product ID right from your PC
- · Stores the details of each transaction for either a single scale or multiple scales
- · Collects data as transactions occur and provides detailed transaction and productivity reports
- · Allows users to add, edit and access IDs over a network connection
- · Reports can be exported in to word processing, spreadsheet or PDF format

# Part Number/Price

Part #	Description	Price
117358	Software package, WeighVault for CW90/90X	\$250.00
125546	Software package, WeighVault for Counterpart	\$250.00

# **Specifications**

#### Minimum System Specifications:

CW-90X or Counterpart® 800+ MHz Intel® compatible processor 1 GB of RAM 750 MB hard drive space TCP/IP connections to a CW-90, CW-90X or Counterpart

#### **Recommended System**

Specifications: 1.0 GHz Intel compatible processor 2 GB of RAM 4 GB hard drive space Microsoft XP SP3 (32-bit), Windows Vista (x86 or x64), Windows 7 (x86 or x64), Windows 8 (64-bit), Windows 10 (64-bit) TCP/IP connections to a CW-90, CW-90X or Counterpart

#### **Network Requirements:**

The PC running the WeighVault service must have a static IP address Known IP address and subnet of the host PC; if connecting via WLAN, known network SSID and security settings (pass keys and phrases) Network policy must allow passwords of six characters

# **Counterpart Functions Only**

- Data Registers: ID code [32 characters]
   Id bit weight [0 places]
  - Unit weight [6 places] Tare weight [6 places] Units field Parts name [32 characters] Part Description [32 characters] Lot number [32 characters] Location [12 characters] Inventory Quantity [7 characters]
- Reports: Part Inventory Activity Location

# **CW-90/90X Functions Only**

- Part Fields:
  - Product ID [4 characters] Two Descriptions Fields [32 Characters each] Target
  - Targe Tare
  - Over
  - Under
- Units
- Reports: Transa
  - Transaction Productivity



# WinWedge<sup>®</sup> TAL Software Wedge Software

# **Specifications**

#### System Requirements:

Any version of Windows® Any Windows PC 4MB of RAM 2MB of hard disk space

#### Communications: WinWedge can collect

data on any serial port (RS-232 or RS-485) and even on multiple ports simultaneously. Also supports full device control.

#### Software Support:

Rice Lake Weighing Systems offers field software support for our software packages. Contact our Service Department for software support. Software support is a chargeable service.



WinWedge ® Serial Device Data Collection Software

# **Standard Features**

- · Input scale or instrument data directly into Excel®, Access®, statistical software, LIMS, MMIs, or any Windows<sup>®</sup> application
- Transfers RS-232 data quickly, accurately and formatted to your exact specifications
- · Powerful DDE options for collecting data from multiple devices simultaneously
- · Extremely easy to set up and use
- WinWedge Pro Additional Features:
- Support for even the most complex devices and serial I/O with advanced data parsing, filtering, formatting and translation
- Support for TCP/IP as well as RS-232 data collection and I/O
- More advanced device control options
- · Additional features such as math functions and virtual instrument mode
- Five RS-232 and TCP/IP communications software products provided free of charge


#### Part Number/Price

Part #	Description	Price
75351	WinWedge <sup>®</sup> TAL software, 32 Std	\$325.00
72304	WinWedge® TAL software, 32 Pro, TCP/Wedge	\$545.00

1. Select how you want the data collected:

🖮 S	oftware Wedge Setup (Untitled)	
<u>F</u> ile	<u>Mode</u> Port <u>D</u> efine <u>A</u> ctivate <u>H</u> elp	
	<ul> <li><u>Send Keystrokes To</u></li> </ul>	
	DDE Server	
	Log To Disk	

2. Choose the communication parameters for your serial device:



3. Define how you want the serial data to be parsed, filtered, and translated:

🖷 Software Wedge Serial Port Settings 🛛 🔹 🔀							
Connector COM1 COM2 COM3 COM4 COM5 COM6 COM6 COM7 COM8 COM8	C 300 C 600 C 1200	<ul> <li>○ 4800</li> <li>○ 9600</li> <li>○ 19200</li> <li>○ 38400</li> <li>○ 56000</li> </ul>	<u>O</u> K <u>C</u> ancel				
- <u>P</u> arity	- <u>D</u> ata Bits -	<u>S</u> top Bits	- <u>F</u> low Control -				
O None	O Five	● 1	None				
○ Odd	C Six	O 1.5	○ Xon/Xoff				
			C Hardware				
	Seven	C 2	C Opto-RS				

4. Activate WinWedge and watch your serial data "pop" into your application:

